



# ASSEMBLY INSTRUCTION

MODEL : E 839

DESCRIPTION : 3 DOORS SHOE CABINET

HARDWARE	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
	WOOD DOWEL 6 X 30	MINIFIX - 12MM (HOUSING)	MINIFIX - 12MM (EURO 24)	MINIFIX CAP -12MM	CB SCREW M3X12MM	P/H SCREW M3.5X16MM	CB SCREW M4X25MM	NAIL 5/8	PVC NAIL WITH PIN 5/8	STOPPER 2 PIN	PVC HANDLE -64	2 TRAY SHOE CABINET -195 (LEFT)	2 TRAY SHOE CABINET -195 (RIGHT)	TRAY -NUT JOINER	TRAY -NUT JOINER
	10	10	10	10	36	6	6	22	4	6	3	3	3	6	6

**PART LIST**

**STEP 1**

**STEP 2**

**STEP 3**

**STEP 4**

**STEP 5**

**STEP 6**

**STEP 7**

**STEP 8**

**STEP 9**

**STEP 10**

**STEP 11**

**STEP 12**

**COMPLETED**